

## RF feeder connector

**ID334**

DIN male for 1-2 super flexible cable SCF



**ID335**

DIN male for 1-2 cable LCF



**ID336**

DIN female for 1-2 super flexible cable SCF



**ID337**

N male right angle for 1-2 super flexible cable SCF



**ID338**

N male right angle for 1-2 LCF



**ID339**

DIN male right angle for 1-2 super flexible cable SCF



**ID340**

DIN male right angle for 1-2 cable LCF



**ID341**

DIN Male right angle for 7-8 LCF



**ID342**

N male for 7-8 cable LCF



**ID343**

N female for 7-8 cable LCF



## RF feeder connector

**ID344**

DIN Female for 7-8 cable LCF



**ID345**

DIN male for 7-8 LDF-50A



**ID346**

DIN male to N female adapter



**ID347**

DIN female to N male adapter



**ID348**

DIN male to N male adapter



**ID349**

DIN female to female adapter



**ID350**

DIN male to female adapter



**ID351**

DIN male to male adapter



**ID352**

DIN male load 5w or 2w



**ID353**

N male for LDF4-50A



**ID354**

DIN male for LDF4-50A

